



3150 Custom Adjustments Guide



- **Height Adjustment/Tilt Lock:** Twist the paddle to adjust the seat height - up or down.
Press button to lock the tilt upright; press again to unlock the tilt.
- **Tilt Tension Control:** Twist to adjust the strength of tension for your chair if you choose to not lock into place.
- **Seat Depth/Recline Position:** Twist the paddle to slide the seat forward or backward.
Press button to adjust and lock into one of 5 upright positions.
- **Activate Swing Arm:** Press up under the swing arms to activate - now swing your arms out of the way.
- **Custom Arm Pad:** With your hand simply move the arm pad to your preferred position.



CONCEPT SEATING

A DIVISION OF LJ DESIGN & MANUFACTURING

3150 Custom Adjustments Guide



- **Lumbar Support Adjustment:** Squeeze to inflate. Open the valve to deflate
- **Backrest Height Adjustment:** Place hands on the bottom and lift to desired height. Lifting all the way up allows the backrest to return to the lowest position.