


3142r1 High Back



No.	Part	Description
1	607-009	7-LEG BASE
2	602-007	CASTER, 60MM ROLL CONTROL (STANDARD), Qty 7
3	602-006	CASTER, GLIDE - SLIP-RESISTANT
4	620-013	STANDARD CYLINDER WITH GREASE PACKET
5	618-006	TILT, CONTROL MECHANISM
6	610-045	ARMREST HANDWHEEL, Qty 2
7	03SA3142-01	3142 SEAT SHELL ASSEMBLY (SHELL, FRAME, ERGO MESH, AND LUMBAR)
8	613-007	SLIDE PAD, RIGHT OR LEFT ARM
9	607-026	RIGHT SWING ARM - BRACKET ONLY
8, 9	620-025	RIGHT SWING ARM - SLIDE PAD ASSEMBLY


No.	Part	Description
11	607-025	LEFT SWING ARM - BRACKET ONLY
8, 11	620-024	LEFT SWING ARM - SLIDE PAD ASSEMBLY
12	613-005	C-LOOP PAD, RIGHT OR LEFT ARM
13	607-013	C-LOOP ARM BRACKET ONLY - RIGHT OR LEFT ARM
12, 13	620-023	RIGHT C-LOOP ARM ASSEMBLY
12, 13	620-022	LEFT C-LOOP ARM ASSEMBLY
16	SA42XX	UPHOLSTERED COVER
17	SA42XXHR	HEADREST
18	608-013	BOTTOM FOAM
19	608-015	BACK FOAM
20	610-005	LUMBAR BULB

3150 TASK & 3150HR OPERATOR



No.	Part	Description	No.	Part	Description
1	607-009	7-LEG BASE	13	607-013	C-LOOP ARM BRACKET ONLY - RIGHT OR LEFT ARM
2	602-007	CASTER, 60MM ROLL CONTROL (STANDARD), Qty 7	12, 13	620-023	RIGHT C-LOOP ARM ASSEMBLY
3	602-006	CASTER, GLIDE - SLIP-RESISTANT	12, 13	620-022	LEFT C-LOOP ARM ASSEMBLY
4	620-013	STANDARD CYLINDER WITH GREASE PACKET	14	610-005	LUMBAR BULB
5	618-004	TILT, CONTROL MECHANISM WITH SEAT SLIDER	15	607-005	J-BAR
6	610-045	ARMREST HANDWHEEL, Qty 2	16	607-024	VAM ASSEMBLY, Qty 2 (Qty 1 if no headrest)
7	06SA3150-01	20" WIDE SEAT PAN ASSEMBLY (FRAME AND ERGO MESH)	17	614-002	ADJUSTABLE HEADREST BRACKET
8	613-007	SLIDE PAD, RIGHT OR LEFT ARM	18	610-057	PLASTIC HEADREST BACKER COVER
9	607-026	RIGHT SWING ARM - BRACKET ONLY	19	SA50XXH	HEADREST (FABRIC, FOAM, BACKER)
8, 9	620-025	RIGHT SWING ARM - SLIDE PAD ASSEMBLY	20	06SA3150-04	SEAT BACK SUB ASSEMBLY (SHELL, FOAM, UPHOLSTERED COVER)
11	607-025	LEFT SWING ARM - BRACKET ONLY	21	SA50XX-BOT	SEAT BOTTOM UPHOLSTERED COVER
8, 11	620-024	LEFT SWING ARM - SLIDE PAD ASSEMBLY	22	608-022	SEAT BOTTOM FOAM
12	613-005	C-LOOP PAD, RIGHT OR LEFT ARM	23	614-004	SEAT BACK PLASTIC COVER
			24	609-004	HEADREST PLUG (ON CHAIRS WITHOUT HEADREST)

3152 TASK & 3152HR OPERATOR



No.	Part	Description	No.	Part	Description
1	607-009	7-LEG BASE	13	607-013	C-LOOP ARM BRACKET ONLY - RIGHT OR LEFT ARM
2	602-007	CASTER, 60MM ROLL CONTROL (STANDARD), Qty 7	12, 13	620-023	RIGHT C-LOOP ARM ASSEMBLY
3	602-006	CASTER, GLIDE - SLIP-RESISTANT	12, 13	620-022	LEFT C-LOOP ARM ASSEMBLY
4	620-013	STANDARD CYLINDER WITH GREASE PACKET	14	610-005	LUMBAR BULB
5	618-004	TILT, CONTROL MECHANISM WITH SEAT SLIDER	15	607-005	J-BAR
6	610-045	ARMREST HANDWHEEL, Qty 2	16	607-024	VAM ASSEMBLY, Qty 2 (Qty 1 if no headrest)
7	06SA3152-01	22" WIDE SEAT PAN ASSEMBLY (FRAME AND ERGO MESH)	17	614-002	ADJUSTABLE HEADREST BRACKET
8	613-007	SLIDE PAD, RIGHT OR LEFT ARM	18	610-057	PLASTIC HEADREST BACKER COVER
9	607-026	RIGHT SWING ARM - BRACKET ONLY	19	SA50XXH	HEADREST (FABRIC, FOAM, BACKER)
8, 9	620-025	RIGHT SWING ARM - SLIDE PAD ASSEMBLY	20	06SA3152-04	SEAT BACK SUB ASSEMBLY (SHELL, FOAM, UPHOLSTERED COVER)
11	607-025	LEFT SWING ARM - BRACKET ONLY	21	SA50XX-BOT	SEAT BOTTOM UPHOLSTERED COVER
8, 11	620-024	LEFT SWING ARM - SLIDE PAD ASSEMBLY	22	608-004	SEAT BOTTOM FOAM
12	613-005	C-LOOP PAD, RIGHT OR LEFT ARM	23	614-004	SEAT BACK PLASTIC COVER
			24	609-004	HEADREST PLUG (ON CHAIRS WITHOUT HEADREST)